

Daikin One+ and One Touch Thermostat Commissioning Menu Outline for VRV, SkyAir, and single/multi-split (P1P2) equipment, v3.2.19 software

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Level 7	Default	Display only?	Conditions		
welcome	english español française	(radio buttons)					english				
	use large font (checkbox)						unchecked				
	continue										
equipment type	unitary (radio button) single/multi-split (S21) (radio button)	cancel continue					unitary				
	VRV, SkyAir, single/multi-split (P1P2) (radio button)										
	continue										
setup	begin setup	(to smart thermostat setup with 5 main steps below)									
	setup options	factory reset									
	learn more	firmware (version #) check for update									
1. Communication	equipment type	unitary mini/multi-split (S21) VRV, SkyAir, mini/multi-split (P1P2) enable mode master (checkbox)					unitary				
	wifi	use wifi					unchecked		The "enable mode master (checkbox)" only shows up when P1P2 is selected.		
		networks	(list of available networks) search again						Only appears when "use wifi" selected		
		internet connected (tickmark)						Yes	Only appears when connected to active wifi network.		
		Daikin One Cloud connected (tickmark)						Yes	Only appears if successfully connect to internet.		
		legal notices	terms of use (text) privacy policy (text) and user license agreement (text)					Yes			
		restart thermostat						Yes			
									If internet connected but not cloud		
	2. Personalization	language	english español française					english			
		use large font (checkbox)						unchecked			
date & time		time zone	(list of North America time zones with radio button selection)							set automatically when connect to WIFI.	
		month/date/year hour/minute/am or pm use 24-hour time format (checkbox)	(selection with spinner) (selection with spinner)					disabled		set automatically when connect to WIFI.	
name		main room upstairs downstairs hallway bedroom kitchen other (other name)	(text entry for other)					main room			
	degree units	fahrenheit celsius					fahrenheit				
3. Equipment Setup	Indoor unit(s)	Indoor unit #0: (model number) (this menu level only shows up if there are multiple indoor units)	Model #: (description based on model number)	(pick from list or manual entry) other (text entry)							
			Serial #:	edit (text entry)							
			unit type	wall-mount unit four-way ceiling cassette one-way blow cassette floor-mount unit concealed ducted unit (unit number selection)					Maybe	Set automatically if model number selected from list.	
			identify unit	run stop				0		If more than 1 indoor unit	
			field settings	mode 20 (selectable) unit number: 0 (selectable)	0 1 ...	0, 1, 2, 3, ... current value highlighted 0, 1, 2, 3, ... current value highlighted				mode 20, unit #0	
				mode 21 (selectable) unit number: 0 (selectable)	15 0 ...	0, 1, 2, 3, ... current value highlighted 0, 1, 2, 3, ... current value highlighted					
				mode 22	15 ...	0, 1, 2, 3, ... current value highlighted					
				mode 25	...	0, 1, 2, 3, ... current value highlighted					
				Save changes?	all units Yes/No	...					Prompted if were changes in menu.
				Identify units	run stop						If more than 1 indoor unit
	load residential field settings	Are you sure...? cancel okay									
		outdoor unit	Model #: (description based on)	(pick from list or manual entry) other (text entry)							
			Serial #	(text entry)							
		group address	assign same	(select address)						Only if central controller connected	
			assign individually	indoor unit #0 indoor unit #1 indoor unit #2 ...	(select address) (select address) (select address) (select address)						
				airmet address	outdoor unit #0 indoor unit #0 indoor unit #1 indoor unit #2 ...	(select address) (select address) (select address) (select address)					Aimet address only appears if multiple indoor units are configured as a group.
		Standard filter		Number of filters Remove equipment? Do you want to remove this equipment?	1, 2 Cancel Continue				1		If standard filter not removed
		Add Equipment	Air quality sensor	(to corresponding setup menus below)							
			Aux heat source	(to corresponding setup menus below)							
			Humidifier	(to corresponding setup menus below)							
Filter box HEPA filter	(to corresponding setup menus below) (to corresponding setup menus below)							Can only add 1 of each type, 1 standard filter added by default.			

	standard filter	(to corresponding setup menus below)						
	VRV IDU Sensor	(to corresponding setup menus below)						
Indoor air quality sensor	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					
	Connection	Aux1 Aux2						If aux heat source added.
Aux heat source	Heat Pump is primary heat source	Control	Heat pump lockout	Heat pump lockout enable (checkbox)	disabled			The HP lockout must be at least 10°F < aux heat lockout.
			Aux heat lockout	Aux heat lockout enable (checkbox)	disabled	15°F (-10°C)		
	T on / T off	Turn on temperature differential:	-7°F to -3°F in 1°F steps (-4.0°C to -1.5 in 0.5°C steps)			-3°F (-1.5°C)		
		Turn off temperature differential:	-4°F to 1°F in 1°F steps (-2°C to 0.5°C in 0.5°C steps)			1°F (0.5°C)		Must be at least 4°F (2°C) above Ton
Aux is primary heat source	Control	Heat pump lockout	Heat pump lockout enable (checkbox)	disabled	15°F (-10°C)			
		Setpoint differential	9°F, -7°F, -5°F, -4°F, or -2°F (-5°C to -1°C in 1°C steps)		-2°F (-1°C)			
T on / T off	Turn on temperature differential:	-2 or -1°F (-1.0 or -0.5°C)			-1°F (-0.5°C)			
	Turn off temperature differential:	1°F (0.5°C)			1°F (0.5°C)		Yes	
	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					
Humidifier	Connection	Aux1 Aux2						If humidifier added
	Control	On with heat On with heat and hum						
	number of pads	1, 2						
	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					
Dehumidifier	Connection	Aux1 Aux2						If dehumidifier added.
	Control	On with cool On with cool and dehum						
	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					
Filter Box	Number of filters	1, 2				1		
	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					If Filter Box added.
HEPA Filter	Number of filters	1, 2				1		
	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					If HEPA filter added.
VRV IDU sensor	Remove equipment?	Do you want to remove this equipment?	Cancel Continue					If VRV IDU sensor added.
4. System Optimization	Error History	(date and time of error) (code - Indoor Unit #) (error description) (minor error code)						
		Clear error history?	Cancel/Continue	Yes/No				
	Calibration	Temperature calibration	-7°F to 7°F in 1°F steps					
		Humidity calibration	-15% to 15% in 1% steps					
	Status	Indoor unit #0	fan tap					If indoor unit supports
			boiler setting					If indoor unit supports
			fan direction					If indoor unit supports
			fan airflow					If indoor unit supports
			fan speed (rpm)					If indoor unit supports
			EVV open degree (pulse)					If indoor unit supports
drain pump							If indoor unit supports	
electric heater							If indoor unit supports	
humidifier							If indoor unit supports	
anti-freeze control							If indoor unit supports	
FLOAT							If indoor unit supports	
T1/T2							If indoor unit supports	
suction temp							If indoor unit supports	
heat exchanger temp							If indoor unit supports	
gas pipe temp							If indoor unit supports	
Indoor unit #1...		fan tap	(repeat of above items)					If indoor unit #1 exists in system.
		fan tap						If outdoor unit supports
		compressor frequency						If outdoor unit supports
		EVV open degree (pulse)						If outdoor unit supports
		adaptive valve						If outdoor unit supports
		outdoor air temp						If outdoor unit supports
		heat exchanger temp						If outdoor unit supports
		discharge temp						If outdoor unit supports
		discharge temp						If outdoor unit supports
		gas pipe temp						If outdoor unit supports
		liquid pipe temp						If outdoor unit supports
		unit operating time						If outdoor unit supports
		fan 1 operating time						If outdoor unit supports
		fan 2 operating time						If outdoor unit supports
		comp.1 operating time						If outdoor unit supports
comp.2 operating time						If outdoor unit supports		
5. Preferences	cool/heat	min/max setpoints	61°F to 90°F in 1°F steps (16°C to 31°C in 0.5°C steps)		61°F to 90°F (16°C to 31°C)		heating: 61°F to 88°F (16°C to 31°C) cooling: 63°F to 90°F (17°C to 32°C)	
		deadband / overcool	Temperature setpoint dead band: 2°F to 9°F in 1°F steps (0°C to 5°C in 0.5°C steps) Overcooling allowed to dehumidify: 0, 1, 2, or 3°F (0, 0.5, 1, or 1.5°C)			4°F / 2°C		0°F / 0°C
	changeover settings	start timer diff	1, 2, 3, 4°F (0.5, 1, 1.5, 2.0°C)			1°F / 0.5°C		
		forced changeover diff	1, 2, 3, 4°F (0.5, 1, 1.5, 2.0°C)			1°F / 0.5°C		
		changeover timer	15 to 60 min. in 15 min. steps			15		
house settings	House size	500 to 10,000 sf in 100 sf steps				not available		
dealer information	name	(text entry)						
	phone	(text entry)						
	email	(text entry)						
	website	(text entry)						
reminders	Standard filter	off, 1, 2, 3, 4, 6, or 12 months			off		If added in "add equipment"	
	Filter box	off, 1, 2, 3, 4, 6, or 12 months			off		If added in "add equipment"	
	HEPA filter	off, 1, 2, 3, 4, 6, or 12 months			off		If added in "add equipment"	
	service reminder	off, 1, 2, 3, 4, 6, or 12 months			off			