

Daikin One+ Thermostat Commissioning Menu Outline for Single/multi-split (S21) equipment, v2.7.10 software

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Default	Display only?	Conditions		
welcome	english español française	(radio buttons)				english				
	use large font (checkbox)					unchecked				
	continue									
equipment type	unitary (radio button)	cancel continue				unitary				
	single/multi-split (S21) (radio button)									
	VRV, SkyAir, single/multi-split (P1/P2) (radio button)									
setup	begin setup	(to smart thermostat setup with 5 main steps below)								
	setup options	factory reset								
	learn more	firmware (version #) check for update								
1. Communication	equipment type	unitary				unitary				
		mini/multi-split (S21) VRV, SkyAir, mini/multi-split (P1/P2)								
	wifi	use wifi								
		networks	(list of available networks) search again						Only appears when "use wifi" selected	
		internet connected (check)					Yes		Only appears when connected to active wifi network.	
		Daikin One Cloud connected (check)					Yes		Only appears if successfully connect to internet.	
		legal notices	terms of use (text) privacy policy (text) end user license agreement (text)				Yes Yes Yes			
2. Personalization	language	english español française				english				
	use large font (checkbox)					unchecked				
	date & time	time zone	(list of North America time zones with radio button selection)						set automatically when connect to WiFi.	
		month/date/year	(selection with spinner)						set automatically when connect to WiFi.	
		hour/minute/am or pm	(selection with spinner)				disabled			
		use 24-hour time format (checkbox)					Pacific		set automatically when connect to mobile app.	
	name	main room upstairs downstairs hallway bedroom kitchen other (other name)	(text entry for other)				main room			
degree units		fahrenheit celsius				fahrenheit				
3. Equipment Setup	Indoor Unit: (model #)	Indoor Unit: (model #) (description based on model number)	(pick from list)							
		edit	(text entry)							
		Serial #:	(text entry)							
	Outdoor Unit: (model #)	unit type	wall-mount ceiling cassette single-flow cassette floor-mount					Maybe	Set automatically when model number selected from list. Default allows manual entry, also allowed if manually entered model number.	
		Outdoor Unit: (model #) (description based on model number)	(pick from list)							
		edit	(text entry)							
	Standard filter	Serial #	(text entry)							
		Number of filters	1, 2				1			
	Add Equipment	Remove equipment	Do you want to remove this equipment?	Yes/No						
		air quality sensor								
		Aux heat source							Can only add 1 of each type.	
		Filter box								
	Indoor air quality sensor	HEPA filter								
		Remove equipment	Do you want to remove this equipment?	Cancel Continue						
		Heat Pump is primary heat source	Connection	Aux1 Aux2						
			Heat pump lockout	Heat pump lockout enable (checkbox)	disabled					If aux heater added.
				-20°F to 65°F in 5°F steps (-27.5°C to 17.5°C in 2.5°C steps)	15°F (-10°C)					The HP lockout must be at least 10°F < aux heat lockout.
Aux heat lockout			Aux heat lockout enable (checkbox)	disabled						
			-10°F to 75°F in 5°F increments (-22.5°C to 22.5°C in 2.5°C steps)	50°F (10°C)						
T on / T off			Turn on temperature differential: -7°F to -3°F in 1°F steps (-4.0°C to -1.5 in 0.5°C steps)	-3°F (-1.5°C)						
		Turn off temperature differential: -4°F to 1°F in 1°F steps (-2°C to 0.5°C in 0.5°C steps)	1°F (0.5°C)					Must be at least 4°F (2°C) above T on		
Aux is primary heat source		Heat pump lockout	Heat pump lockout enable (checkbox)	disabled					If aux heater added.	
	-20°F to 65°F in 5°F steps (-27.5°C to 17.5°C in 2.5°C steps)	15°F (-10°C)					The HP lockout must be at least 10°F < aux heat lockout.			
	Setpoint differential	-9°F, -7°F, -5°F, -4°F, or -2°F (-5°C to -1°C in 1°C steps)	-2°F (-1°C)							
	T on differential	Turn on temperature differential: -1 or -2°F (-0.5 or -1.0°C)	-1°F (-0.5°C)							
T off differential	Turn off temperature differential: 1°F (0.5°C)	1°F (0.5°C)				Yes				
Remove equipment	Do you want to remove this equipment?	Cancel Continue								
Filter box	Number of filters	1, 2				1		If filter box added.		
	Remove equipment	Do you want to remove this equipment?	Cancel Continue							
HEPA filter	Number of filters	1, 2				1		If HEPA filter added		
	Remove equipment	Do you want to remove this equipment?	Cancel Continue							
4. System Optimization	Error History	(date and time of error) (code - Indoor Unit #) (error description) (minor error code)								
		Clear error history?	Cancel/Continue	Yes/No						
	Calibration	Temperature calibration	-7°F to 7°F in 1°F steps (or) -3.5°C to 3.5°C in 0.5°C steps				0°F			
		Humidity calibration	-15% to 15% in 1% steps				0%			
	Status	Indoor	suction temp							
			therm (on/off)							
		Outdoor	air temp						Emura only	
			serial com version							
			discharge temperature							
			heat exchanger temp						Emura only	
electric current flow								Emura only		
fan RPM								Emura only		
liquid pipe temp						Emura only				
power consumption						Emura only				
EEV aperture						Emura only				
min/max setpoints	min/max setpoints	57°F to 90°F in 1°F increments				57°F to 90°F		heating: 57 to 86 cooling: 64 to 90		
	deadband / overcool	Temperature setpoint dead band: (2°F to 9°F in 1°F steps) Overcooling allowed to dehumidify: (0, 1, 2, or 3°F)				4°F				

5. Preferences	cool/heat	changeover settings	start timer diff	1, 2, 3, 4°F (0.5, 1, 1.5, 2.0°C)		1°F		
			forced changeover diff	1, 2, 3, 4°F (0.5, 1, 1.5, 2.0°C)		1°F		
			changeover timer	15 to 60 min. in 15 min. steps		15	Timer started on heat-to-cool or cool-to-heat transition so doesn't change modes too quickly. Timer is ignored if forced changeover diff is reached.	
	house settings	House size	500 to 10,000 sf in 100 sf steps					
	dealer information	name	(text entry)					
		phone	(text entry)					
		email	(text entry)					
		website	(text entry)					
	reminders	message	(text entry)					
		Standard filter	off, 1, 2, 3, 4, 6, or 12 months			off	if added in "add equipment"	
		Filter box	off, 1, 2, 3, 4, 6, or 12 months			off	if added in "add equipment"	
		HEPA filter	off, 1, 2, 3, 4, 6, or 12 months			off	if added in "add equipment"	
		service reminder	off, 3, 6, or 12 months			off		